

INSTALLATION INSTRUCTIONS FOR DROPSPOT[™] WATER FILTER



FA-3000 3000 Gallon Water Filter (FC3000R) Kit for DRS-100 Bottle Fillers

FC3000R is certified by IAPMO R&T to NSF/ANSI 42, NSF/ANSI 53, and NSF/ANSI 401 for the reduction of particulate class I, lead, and cyst when used in FA3000-DRS100.



SLOAN[®] LIMITED WARRANTY SUMMARY

Sloan Valve Company ("Sloan"), warrants its products against defects in materials and workmanship, excluding damage caused by matters beyond Sloan's reasonable control. Instructions for filing claims can be found in the Limited Warranty which can be obtained at www.sloan.com or by requesting a free copy by telephone at 888.756.2614. Sloan will repair or replace your defective product, or provide a refund, as your exclusive remedy. This is only a general summary of Sloan's Limited Warranty so it is important to note that the specific terms, conditions, limitations and exclusions, including the duration of warranty coverage for your particular Sloan product, are contained in the actual Sloan Limited Warranty. The Limited Warranty is subject to applicable laws in your country, state, province or other jurisdiction—and disputes arising under the Limited Warranty are to be resolved by binding arbitration unless you provide Sloan with an opt-out notice no later than 30 days after your purchase date. In case of a conflict with this summary, the terms and conditions set forth in the complete Limited Warranty will prevail.

IMPORTANT INFORMATION

- Install in compliance with local and state regulations.
- Install in cold water applications only.
- DO NOT USE where the water is microbiologically unsafe or of unknown quality without adequate disinfection before or after the unit.
- DO NOT USE this system on water containing hardness greater than 50 mg/L (3 grains per gallon) without pretreatment to remove hardness.
- Rated maximum service flow = 1.25 gpm
- Maximum operating pressure = 125 psi
- Maximum operating temperature = 130°F
- · Spent absorption media should not be regenerated and used.

TOOLS REQUIRED FOR INSTALLATION

- Philips screwdriver (not provided)
- Universal Maintenance Tool (provided with Bottle Filler)


- If absorption media is affected by chlorine, influent should be treated to remove chlorine.
- WARNING: This system is for use on water supplies that have been treated to public
 water systems standards. This system has been tested to demonstrate effective
 reduction of microcystins, however, in the event of a reported cyanotoxin event in your
 water supply, other cyanotoxins may be present in the drinking water which may not
 be effectively reduced by this system. In the event of a cyanotoxin notification, follow
 the recommendations of your drinking water authority.
- This system conforms to NSF/ANSI 53 and has been verified and substantiated by test data.

Universal Maintenance Tool DO NOT DISCARD!



NEW INSTALLATIONS

Follow the instructions on this page for new Bottle Filler installations. For existing installations, see the next page.




EXISTING INSTALLATIONS

Follow the instructions on this page to add the water filter to an existing Bottle Filler. For new installations, see the previous page.



Using a 5/32" hex driver or Allen wrench, remove top screw from bottle filler housing and open unit.






3

Turn off water supply stop.

IMPORTANT: If unit is refrigerated, disconnect chiller power supply.


Disconnect supply side tubing from solenoid.



4

Mount filter cartridge to upper corner bracket using the two (2) screws provided.

IMPORTANT: The IN port should be furthest from the solenoid and OUT should be closest to the solenoid.



- 5 Connect existing supply hose to IN port.
- Connect OUT port to solenoid port. 6
- Run 6.25 gallons of water through the filter before use.

IMPORTANT

Run 6.25 gallons of water through the filter before use.

Change the filter when the LED is illuminated, or if water becomes cloudy, decreased water flow or pressure, and/or the water develops a bad taste. See Replacement Filters table below.

REPLACEMENT FILTERS (SOLD SEPARATELY)		
Code No.	Part No.	Description
33830003	FC3000R	3000 Gallon Filter Cartridge (1 pack)
33830014	FC3000M	3000 Gallon Filter Cartridge (20 pack)

When assistance is required, please contact Sloan Technical Support at 1.888.SLOAN.14 or 1.888.756.2614.

The information contained in this document is subject to change without notice.

SLOAN • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131

Phone: +1.800.9.VALVE.9 or +1.800.982.5839 • Fax: +1.800.447.8329 • www.sloan.com